

STARBORN.

INSTMT8R

CAP-TOR® xd

Metal

Composite/PVC Deck

Screws for Metal Framing

Follow all manufacturer installation instructions, including specifications for screw spacing, edge/end distances, and gapping.

INSTALLATION INSTRUCTIONS

For Color Match Surface Fastening

- Install flush with deck surface
- Drive screw into board.
- Once drill point is embedded into board continue driving in a slow steady fashion with consistent pressure.
- **IMPORTANT:** Do not predrill through the board. Do not use an impact driver.

For use with PRO PLUG SYSTEM

- Use 1-5/8" CAP - TOR® xd Metal screws and purchase plugs and PVC/Composite Tool separately.
- Drive screw into board.
- Once drill point is embedded into board continue driving in a slow and steady fashion with consistent pressure.
- **IMPORTANT:** Do not predrill through board. However, for harder deck boards, use a 7/32" drill bit to dimple the surface of the board (approx. 1/8" deep). Do not use an impact driver.